

Supplementary information for EU Devices in the LoRaWAN $^{\!\scriptscriptstyle (\!g\!)}$ Showcase catalogue. Version 1.0

Version of Questionnaire form from the Customer/ Device Manufacturer

Version	Date	Author	Update
1.0			Initial release from manufacture

Supplementary Information on certified device

1 Supplementary information	
1.1 Manufacturer or Brand name	Ursalink
1.2 Website	www.ursalink.com
1.3 Sales / Marketing contact person, email:	ivete@ursalink.com
1.4 Technical contact person, email:	near_lxj@yeastar.com
1.5 Commercial Product name	Environment Monitoring Sensors-Ultrasonic Distance/Level Sensor
1.6 Product code used when ordering / article number	9015100000
1.7 Product Version :	V1.0
Hardware version:	V1.2
Firmware version:	V2.3
1.8 In what countries is the product available	worldwide
1.9 What date was / is the market introduction for this device / product?	2020/3/20
1.10 Is the device already working on a public LoRaWAN network. If yes specify at which public operator, country and number of deployed devices on that network:	⊠ Yes: □ No
1.11 What functionality does the device provide and which sensor(s) does it contain?	Use case: EM500-UDL is an outdoor environment monitoring sensor mainly used to measure distance without object interface contact. EM500-UDL device is battery powered and designed for



	multiple mounting ways. It is equipped with NFC (Near Field Communication) and can easily be configured from a smartphone or a PC software.
	Short behavior description: Sensor data are transmitted in real-time using standard LoRaWAN protocol. LoRaWAN enables encrypted radio transmissions over long distance while consuming very little power. The user can obtain sensor data and view the trend of data change through Ursalink Cloud or thr ough the user's own Network Server.
1.12 Accuracy & resolution for every sensor or measurement made by the device	
Name:	HRXL-MaxSonar-WR sensor
sensor accuracy (incl. unit): +/-	± 1%
resolution (incl. unit):	1 mm
measurement parameter:	Distance
measurement range	0.3-10m(Customize for snow level detection)
1.13 Uplinks are: Periodic:	
Period:	10min
Explanation:	
Keep alive message period:	1day
Event triggered how:	
1.14 Parameter configuration of device (e.g.	⊠ Remotely:
transmission or measurement interval, threshold levels,	
etc.)	Specify if other:
	☐ Locally:
	☐ Via CLI: specify type of connector:
	☑ Via NFC:
	☐ Specify if other:
1.15 Does the application server send downlinks to the	⊠ Yes: (why/how often/typical size)
devices?	
	□No
1.16 Operating temperature of device	Minimum -30 °C
- x °C to + x °C	Maximum +65 °C
1.17 Is the payload structure available for decoding?	☐ Yes: ⊠ No
	Please attach the payload structure
	(+example of decoded payload)



1.18 Is there a decode-API available	☐ Yes: ☐ No
	Please attach the API documentation
1.19 Is the firmware upgradeable and how?	☐ Yes: (how)
1.20 How can the device be reset to factory default	Reset via PC Software;Reset via Button
settings?	
1.21 How can the device he forced to re initiate the isin	via Smartphone APP;via PC Software;via Button
1.21 How can the device be forced to re-initiate the join procedure?	via Smartphone AFF, via FC Software, via Button
1.22 Product certifications (IP rating, ATEX,)	1. IP rating: IP66
(ii raing, , r. 2, t,)	2. ATEX compliance:
	Other:
1.23 Which regulatory certifications are available (RED,	⊠RED
CE, EMC)?	☑ CE
	⊠ EMC
	Attach proof of certification to the mail in which this
	document is sent to a public operator
1.24 Power Supply	External power supply:
	connection:
	voltage:
	amperage:
	│
	battery type: 19000 mAh Li-SoCl2 battery
	chemical composition: Li-SoCl2
	Battery self-discharge (%/year): 1.5
	Battery shelf life: >10 year
	capacity: 19000 mAh
	weight: 100g
	rechargeable: ☐ Yes: ⊠ No
1.25 Powering device on and off	
How is the device turned ON ?	Turn ON via Smartphone APP;Turn ON via PC
How is the device turned OFF?	Software; Turn ON via Button
	Turn OFF via Smartphone APP;Turn OFF via PC Software;Turn OFF via Button
	Continuito, Furni Of F. via Battori
1.26 Dimensions of device	15.61 × 7.1 × 6.95cm
(Length x width x height)	





1.27 Weight of full device	g
1.28 Mounting of device	
1. How to mount?	Wall Mounting, Pole Mounting, DIN Rail Mounting
2. How to mount for best	1.Ensure the location of EM500-UDL is within the
antenna propagation	communication range of LoRaWAN gateway.
	2.Device must sit in a vertical position on top of the object and be fitted such that it has a clear path to
	the object.
	3.Place device where it is not close to side-wall and
	without internal obstructions that block the ultrasonic signal.
	4.Do not place device in the center of arched or
	circular container tops since it will cause multiple
	echos.
	5.Do not place the device above the container inlet
	orifice.



2 LoRaWAN Device Information

2.1 DevEUI Range (IEEE Compliance)	From :24E1240000000000 To : 24E124FFFFFFFFF
2.2 LoRaWAN Class	☑ Class A ☐ Class B ☐ Class C
2.3 For Class C Device: Device Under Test restores previous RF settings at boot?	☐ Yes ☐ No
2.4 In what LoRaWAN region/frequency ranges is the product available	⊠ EU863-870 ☐ US902-928 ☐ AS923 ☐ IN865-867 ☐ KR920-923 ☐ Other
2.5 Is the LoRaWAN test mode supported?	⊠ Yes □ No, why not
2.6 Tested and certified against which LoRaWAN Specification(s)	☐ V1.0 ☐ V1.0.1 ☐ V1.0.2 revB ☐ V1.0.3 ☐ V1.1.x ☐ Other:
2.7 Link to document on the LoRa Alliance website	Link:
2.8 Which TX power is used in production devices by default?	
- if LW 1.0.2 rev A or older is used:	☐ TXPower 0 (20dBm) ☐ TXPower 1 (14dBm) ☐ TXPower 2 (11dBm) ☐ TXPower 3 (8dBm) ☐ TXPower 4 (5dBm) ☐ TXPower 5 (2dBm) ☐ other TXPower (dBm)
- if LW 1.0.2 rev B or newer is used	 □ TXPower 0 (MaxEIRP) □ TXPower 1 (MaxEIRP-2dB) □ TXPower 2 (MaxEIRP-4dB) □ TXPower 3 (MaxEIRP-6dB) □ TXPower 4 (MaxEIRP-8dB) □ TXPower 5 (MaxEIRP-10dB)



	☐ TXPower 6 (MaxEIRP-12dB)
	☐ TXPower 7 (MaxEIRP-14dB)
	□other TXPower
	(Max EIRP : dB)
	(Max 2n ti : db)
O O Militalia TV managara and a dilambia	
2.9 Which TX powers are supported by the	
device in production	
- if LW 1.0.2 rev A or older is used:	☐ TXPower 0 (20dBm)
11 211 110.2101 11 01 01 01 0 0 0 0 0 0 0 0 0 0 0 0	
	☐ TXPower 1 (14dBm)
	☐ TXPower 2 (11dBm)
	TXPower 3 (8dBm)
	, ,
	TXPower 4 (5dBm)
	☐ TXPower 5 (2dBm)
	Cathor TVDovice (dDm)
	□other TXPower (dBm)
- if LW 1.0.2 rev B or newer is used	☑ TXPower 0 (MaxEIRP)
	☐ TXPower 1 (MaxEIRP-2dB)
	☐ TXPower 2 (MaxEIRP-4dB)
	□ TXPower 3 (MaxEIRP-6dB)
	☐ TXPower 4 (MaxEIRP-8dB)
	☐ TXPower 5 (MaxEIRP-10dB)
	☑ TXPower 6 (MaxEIRP-12dB)
	☑ TXPower 7 (MaxEIRP-14dB)
	(Max EIRP : dB)
2.9 Which LoRaWAN Specification	□V1.0
is currently supported on	□V1.0.1
the production devices?	□V1.0.2 revA
	⊠V1.0.2 revB
	□V1.0.4
	_
	□V1.1.x
	☐Other:
0.40.10(1)	
2.10 Will you re-certify your device	⊠Yes.
when a new major LoRaWAN	□No, why:
specification version is released	
ap a simulation i o i o i o i o i o i o i o i o i o	



2.11 Has Interoperability prequalification testing been done?	 ☑Yes. ☐No, why: Which Network Servers ☑Actility ☑Loriot ☑TTI ☐Other: Specify: Please attach all the test reports.
2.12 Is Activation Type OTAA the default	⊠Yes. □No, why :
2.13 For OTAA, is AppKey unique for each device?	□Yes. ⊠No.
2.14 Is ADR implemented? Recommendation: ADR should always be activated. Exceptions can be made for moving devices but will need to be explained.	☑Activated☑Deactivated, why :☑Configurable by user (recommendation: Activated by default)☑Mixed, explain:
2.15 What values did you implement for: - ADR_ACK_LIMIT: - ADR_ACK_DELAY:	64recommended value: 64 32recommended value: 32
2.16 Do you use unconfirmed and/or confirmed uplinks and what is the data rate, timing and power back off algorithm?	□unconfirmed □confirmed, when and why: □Both, which is used when and why: When confirmed mode is enabled Data rate, timing and power back-off algorithm (only if you use confirmed uplinks):
Upon reception of a confirmed downlink message, is the next uplink sent immediately after the downlink ?Answers (radio buttons)	□Yes. ⊠No, why :
2.17 Is the device doing a periodical rejoin? (only for OTAA)	☐Yes (frequency): ☑No. Why? How to trigger a rejoin? Use the restart button



2.18 Is the first join request sent on SF12? 2.19 On what SF and power setting is the first	☐Yes. ☑No, why: Because of the duty cycle Explain the JoinRequest sequence if no JoinAccept is received - data rate, timing and power back-off algorithm. SF: SF10
uplink (after join procedure) done?	TXPower: TXPower0
2.20 Are you doing periodically reset of Uplink frame counter?	☐Yes (frequency/why): ⊠No.
2.21 If LoRaWAN 1.0.x, DevNonce behaviour :	☒ Based on a random value☒ Monotonically increasing never-wrapping counter
2.22 Uplink DataRate (0-7 supported)	Min: 0 Max: 6
2.23 RX1 Data Rate Offset	☑Default LoRaWAN in regards of ISM band ☐Other:
2.24 RX1 Delay	☑Default LoRaWAN in regards of ISM band ☐Other:
2.25 RX2 Data Rate	☑Default LoRaWAN in regards of ISM band ☐Other:
2.26 RX2 Frequency	☑Default LoRaWAN in regards of ISM band ☐Other:
2.27 RX1 Delay on JoinRequest (OTAA devices only)	☑Default LoRaWAN in regards of ISM band ☐Other:
2.28 Mobility Profile (how your device moves)	⊠Near static □Walking speed □Vehicle speed □Random
2.29 Frame Counters Up To 32-bits	⊠Frame counter-up □Frame counter-down



2.30 Which MAC commands does the device	⊠LinkCheckReq / LinkCheckAns
support	⊠TXParamSetupReq / TXParamSetupAns
	⊠LinkADRReq / LinkADRAns
	⊠DutyCycleReq / DutyCycleAns
	⊠RXParamSetupReq /RXParamSetupAns
	⊠DevStatusReq / DevStatusAns
	⊠NewChannelReq / NewChannelAns
	⊠TXTimingSetupReq / TXTimingSetupAns
2.31 LoRaWAN Stack Type (optional)	⊠Semtech/Stackforce
	☐Semtech/Stackforce with modifications
	□IBM
	☐IBM with modifications
	☐Proprietary- Other, name it:
2.32 LoRaWAN Stack Version (optional)	V1.0.2
2.33 LoRa Radio Hardware (optional)	⊠Proprietary:
	SX chip used:
	□LoRaWAN Modem/Module:
	Manufacturer:
	Part Number:
	Firmware revision:
2.34 Multicast support (optional)	☐Yes:
	Multicast DevAddr:
	Multicast AppSKey:
	Multicast NwkSKey:
	Payload:
	Port:
	⊠No.



3 Radio Frequency Information

3.1 Type of Antenna	□Wire
	□PCB
	□External
	⊠Other: (which type) Microstrip (Patch) Antennas
3.2 Antenna gain [dBi or dBd]	1.4dBi or
	dBd
3.3 Did you measure and take into account the	☐Yes, dB loss
loss between the modem and the antenna?	⊠No, why: We have match the impedance between the
	moderm and the antenna.
3.4 For LW 1.0.2 rev A or older devices: which	☐ TXPower 0 (20dBm)
TXPower setting should be used on the	☐ TXPower 1 (14dBm)
network for your device*:	<u> </u>
0.5 Did	· · · · · · · · · · · · · · · · · · ·
, ,	
	∐No, why:
EIRP)*.	
3.4 For LW 1.0.2 rev A or older devices: which TXPower setting should be used on the network for your device*: 3.5 Did you calibrate your device with the antenna gain and measured loss in between the chipset and antenna? This so that your device emits with maximal power when using TXPower 1 for LW 1.0.2 rev A or older devices (= 14dBm) and TXPower 0 for LW 1.0.2 rev B or newer devices (= MaxEIRP or 16.15dBm	No, why: We have match the impedance between the moderm and the antenna. ☐ TXPower 0 (20dBm)



4 Battery and TX Power Information

Please indicate if you do not want Section 4 displayed on the LoRa Alliance Website ☐Yes

If yes please supply contact details for the operators to request the information for Section 4

4.1 Battery consumption of the	TX current: 62-64mA
device (including modem,	RX current: 6.7 mA
sensors and all other electronics	Idle time current: 0.0058mA
4.2 Estimated battery life in years based on the number	Battery life in years
of transmissions (including sensor readings) at SF7,	SF7 SF10 SF12
SF10 & SF12 with your battery self-discharge and aging over time taken into account.	등 144 62.98 27.6 8.1
over time taken into account.	ੇ ਜੂੰ 96 75.18 37.2 11.78
Assumptions:	48 93 57 21.5
- Product shelf life before use:	$\frac{9}{9} \cdot \frac{9}{9} \cdot \frac{9}{9} \cdot 24 \cdot 106 = 77.9 = 36.6$
Maximum 1 year.	SF7 SF10 SF12 ipp 144 62.98 27.6 8.1 ipp 96 75.18 37.2 11.78 d
- At an environment temperature	$\frac{6}{6}$
of 20°C.	
0120 0.	
- LoRaWAN specification used for battery life	□LW1.0.1
calculation:	□LW1.0.2 revA
	⊠LW1.0.2 revB
	☐Other:
- TX power setting (txpower)	□LW1.0.1
used for battery life calculation:	□LW1.0.2 revA
	⊠LW1.0.2 revB
	Other:
- Payload size used for battery life	16 bytes
calculation (should be average	
payload size of production device):	
- Additional assumptions or	
comments on battery life (Typical usage	



4.3 Which TX power setting (TXPower) was used in the RF test?	
- If LW 1.0.2 rev A or older device:	☐ TXPower 0 (20dBm) ☐ TXPower 1 (14dBm) ☐ TXPower 2 (11dBm) ☐ TXPower 3 (8dBm) ☐ TXPower 4 (5dBm) ☐ TXPower 5 (2dBm) ☐ other TXPower (dBm)
- If LW 1.0.2 rev B or newer device:	☐ TXPower 0 (MaxEIRP) ☐ TXPower 1 (MaxEIRP-2dB) ☐ TXPower 2 (MaxEIRP-4dB) ☐ TXPower 3 (MaxEIRP-6dB) ☐ TXPower 4 (MaxEIRP-8dB) ☐ TXPower 5 (MaxEIRP-10dB) ☐ TXPower 6 (MaxEIRP-12dB) ☐ TXPower 7 (MaxEIRP-14dB) ☐ Other TXPower 14.6 (MaxEIRP-1.4 dBdBm)
4.4 Is this the same TX power setting (TXPower) used by default in production devices (before network ADR)?	⊠Yes, Txpower0 □No, why:
4.5 Maximum ERP measured: (ERP = EIRP - 2.15 dB; LoRaWAN allows 14 dBm ERP)	14 dBm
4.6 TRP measured: (TRP is based on EIRP) This gives an idea about the directivity of the antenna.	14 dBm
3.10 TIS measured on RX1:	For RX1-SF12BW125 on 868.3MHz -146 dBm
3.11 TIS measured on RX2	For RX2-SF12BW125 on 869.525 MHz: -146 dBm