

Supplementary information for EU Devices in the LoRaWAN® Showcase catalogue. Version 1.0

Version of Questionnaire form from the Customer/ Device Manufacturer

Version	Date	Author	Update
1.0			Initial release from manufacture

Supplementary Information on certified device	
1 Supplementary information	
1.1 Manufacturer or Brand name	Ursalink
1.2 Website	www.ursalink.com
1.3 Sales / Marketing contact person, email:	ivete@ursalink.com
1.4 Technical contact person, email:	near_lxj@yeastar.com
1.5 Commercial Product name	Environment Monitoring Sensors-Ultrasonic Distance/Level Sensor
1.6 Product code used when ordering / article number	9015100000
1.7 Product Version : Hardware version: Firmware version:	V1.0 V1.2 V2.3
1.8 In what countries is the product available	worldwide
1.9 What date was / is the market introduction for this device / product?	2020/3/20
1.10 Is the device already working on a public LoRaWAN network. If yes specify at which public operator, country and number of deployed devices on that network:	⊠ Yes: □ No
1.11 What functionality does the device provide and which sensor(s) does it contain?	Use case: EM500-UDL is an outdoor environment monitoring sensor mainly used to measure distance without object interface contact. EM500-UDL device is battery powered and designed for multiple mounting ways. It is equipped with NFC (Near Field Communication) and can easily be configured from a smartphone or a PC software.
	Short behavior description: Sensor data are transmitted in real-time using standard LoRaWAN protocol. LoRaWAN enables encrypted radio transmissions over long distance while consuming very little power. The user can obtain sensor data and view the trend of data change through Ursalink Cloud or thr ough the user's own Network Server.



1.12 Accuracy & resolution for every sensor or measurement made by the device	
Name:	HRXL-MaxSonar-WR sensor
sensor accuracy (incl. unit): +/-	± 1%
resolution (incl. unit):	1 mm
measurement parameter:	Distance
·	0.3-10m(Customize for snow level detection)
measurement range	
1.13 Uplinks are: Periodic:	
Period:	10min
Explanation:	
Keep alive message period:	1day
Event triggered how:	
1.14 Parameter configuration of device (e.g.	⊠ Remotely:
transmission or measurement interval, threshold levels,	
etc.)	Specify if other:
	Locally:
	☐ Via CLI: specify type of connector:
	☑ Via NFC:
	☐ Specify if other:
1.15 Does the application server send downlinks to the	
devices?	
	□No
1.16 Operating temperature of device	Minimum -30 °C
1.16 Operating temperature of device - x °C to + x °C	
	Maximum +65 °C
1.17 Is the payload structure available for decoding?	☐ Yes: ⊠ No
	Please attach the payload structure
	(+example of decoded payload)
1.18 Is there a decode-API available	☐ Yes: ⊠ No
	Please attach the API documentation
	r reads attach the fill r assumentation
1.19 Is the firmware upgradeable and how?	⊠ Yes: (how)
1.19 is the limware upgradeable and now!	☑ Tes. (How)
1.20 How can the device be reset to factory default	Reset via PC Software;Reset via Button
settings?	
1.21 How can the device be forced to re-initiate the join	via Smartphone APP;via PC Software;via Button
procedure?	
1.22 Product certifications (IP rating, ATEX,)	1. IP rating: IP66
	2. ATEX compliance:
	Other:
1.23 Which regulatory certifications are available (RED,	⊠ RED
CE, EMC)?	☐ CE
()	
	⊠ EMC
	Attach proof of certification to the mail in which this



	document is sent to a public operator
1.24 Power Supply	□ External power supply: connection: voltage: amperage: □ Internal battery: battery type: 19000 mAh Li-SoCl2 battery chemical composition: Li-SoCl2 Battery self-discharge (%/year): 1.5 Battery shelf life: >10 year capacity: 19000 mAh weight: 100g rechargeable: □ Yes: □ No
1.25 Powering device on and off How is the device turned ON? How is the device turned OFF?	Turn ON via Smartphone APP;Turn ON via PC Software;Turn ON via Button Turn OFF via Smartphone APP;Turn OFF via PC Software;Turn OFF via Button
1.26 Dimensions of device (Length x width x height)	15.61 × 7.1 × 6.95cm
1.27 Weight of full device	g
1.28 Mounting of device1. How to mount?2. How to mount for best antenna propagation	Wall Mounting, Pole Mounting, DIN Rail Mounting 1.Ensure the location of EM500-UDL is within the communication range of LoRaWAN gateway. 2.Device must sit in a vertical position on top of the object and be fitted such that it has a clear path to the object. 3.Place device where it is not close to side-wall and without internal obstructions that block the ultrasonic signal. 4.Do not place device in the center of arched or circular container tops since it will cause multiple echos. 5.Do not place the device above the container inlet orifice.



2 LoRaWAN Device Information

2.1 DevEUI Range (IEEE Compliance)	From :24E1240000000000 To: 24E124FFFFFFFFF
2.2 LoRaWAN Class	☐ Class A ☐ Class B ☐ Class C
2.3 For Class C Device: Device Under Test restores previous RF settings at boot?	☐ Yes ☐ No
2.4 In what LoRaWAN region/frequency ranges is the product available	□ EU863-870 □ US902-928 □ AS923 □ IN865-867 □ KR920-923 □ Other
2.5 Is the LoRaWAN test mode supported?	⊠ Yes □ No, why not
2.6 Tested and certified against which LoRaWAN Specification(s)	☐ V1.0 ☐ V1.0.1 ☑ V1.0.2 revB ☐ V1.0.3 ☐ V1.1.x ☐ Other:
2.7 Link to document on the LoRa Alliance website	Link:
2.8 Which TX power is used in production devices by default?	
- if LW 1.0.2 rev A or older is used:	☐ TXPower 0 (20dBm) ☐ TXPower 1 (14dBm) ☐ TXPower 2 (11dBm) ☐ TXPower 3 (8dBm) ☐ TXPower 4 (5dBm) ☐ TXPower 5 (2dBm) ☐ other TXPower (dBm)
- if LW 1.0.2 rev B or newer is used	 □ TXPower 0 (MaxEIRP) □ TXPower 1 (MaxEIRP-2dB) □ TXPower 2 (MaxEIRP-4dB) □ TXPower 3 (MaxEIRP-6dB) □ TXPower 4 (MaxEIRP-8dB) □ TXPower 5 (MaxEIRP-10dB) □ TXPower 6 (MaxEIRP-12dB) □ TXPower 7 (MaxEIRP-14dB)
	□other TXPower (Max EIRP : dB)



2.9 Which TX powers are supported by the device in production	
- if LW 1.0.2 rev A or older is used:	☐ TXPower 0 (20dBm) ☐ TXPower 1 (14dBm) ☐ TXPower 2 (11dBm) ☐ TXPower 3 (8dBm) ☐ TXPower 4 (5dBm) ☐ TXPower 5 (2dBm) ☐ Other TXPower (dBm)
- if LW 1.0.2 rev B or newer is used	□ TXPower 0 (MaxEIRP) □ TXPower 1 (MaxEIRP-2dB) □ TXPower 2 (MaxEIRP-4dB) □ TXPower 3 (MaxEIRP-6dB) □ TXPower 4 (MaxEIRP-8dB) □ TXPower 5 (MaxEIRP-10dB) □ TXPower 6 (MaxEIRP-12dB) □ TXPower 7 (MaxEIRP-14dB) (Max EIRP : dB)
2.9 Which LoRaWAN Specification is currently supported on the production devices?	□V1.0 □V1.0.1 □V1.0.2 revA □V1.0.2 revB □V1.0.4 □V1.1.x □Other:
2.10 Will you re-certify your device when a new major LoRaWAN specification version is released	⊠Yes. □No, why :
2.11 Has Interoperability prequalification testing been done?	 ☑Yes. ☐No, why: Which Network Servers ☑Actility ☑Loriot ☑TTI ☐Other: Specify: Please attach all the test reports.
2.12 Is Activation Type OTAA the default	⊠Yes. □No, why :
2.13 For OTAA, is AppKey unique for each device?	□Yes. ⊠No.



2.14 Is ADR implemented? Recommendation: ADR should always be activated. Exceptions can be made for moving	⊠Activated □Deactivated, why :
devices but will need to be explained.	☐Configurable by user (recommendation: Activated by default) ☐Mixed, explain:
0.45 \\ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \	
2.15 What values did you implement for: - ADR_ACK_LIMIT: - ADR_ACK_DELAY:	64recommended value: 64 32recommended value: 32
7.81.5.161.6222.111	52.555mmond54 value: 52
2.16 Do you use unconfirmed and/or confirmed uplinks and what is the data rate, timing and power back off algorithm?	□unconfirmed □confirmed, when and why: □Both, which is used when and why: When confirmed mode is enabled Data rate, timing and power back-off algorithm (only if you use confirmed uplinks):
Upon reception of a confirmed downlink message, is the next uplink sent immediately after the downlink ?Answers (radio buttons)	□Yes. ⊠No, why :
2.17 Is the device doing a periodical rejoin? (only for OTAA)	☐Yes (frequency): ☑No. Why? How to trigger a rejoin? Use the restart button
2.18 Is the first join request sent on SF12?	☐Yes. ☑No, why: Because of the duty cycle Explain the JoinRequest sequence if no JoinAccept is received - data rate, timing and power back-off algorithm.
2.19 On what SF and power setting is the first uplink (after join procedure) done?	SF: SF10 TXPower: TXPower0
2.20 Are you doing periodically reset of Uplink frame counter?	□Yes (frequency/why): ⊠No.
2.21 If LoRaWAN 1.0.x, DevNonce behaviour :	☑ Based on a random value☐ Monotonically increasing never-wrapping counter
2.22 Uplink DataRate (0-7 supported)	Min: 0 Max: 6
2.23 RX1 Data Rate Offset	☑Default LoRaWAN in regards of ISM band ☐Other:
2.24 RX1 Delay	☑Default LoRaWAN in regards of ISM band ☐Other:
2.25 RX2 Data Rate	☑Default LoRaWAN in regards of ISM band ☐Other:



2.26 RX2 Frequency	☑Default LoRaWAN in regards of ISM band ☐Other:
2.27 RX1 Delay on JoinRequest (OTAA devices only)	☑Default LoRaWAN in regards of ISM band ☐Other:
2.28 Mobility Profile (how your device moves)	⊠Near static □Walking speed □Vehicle speed □Random
2.29 Frame Counters Up To 32-bits	⊠Frame counter-up □Frame counter-down
2.30 Which MAC commands does the device support	 ☑LinkCheckReq / LinkCheckAns ☑TXParamSetupReq / TXParamSetupAns ☑LinkADRReq / LinkADRAns ☑DutyCycleReq / DutyCycleAns ☑RXParamSetupReq /RXParamSetupAns ☑DevStatusReq / DevStatusAns ☑NewChannelReq / NewChannelAns ☑TXTimingSetupReq / TXTimingSetupAns
2.31 LoRaWAN Stack Type (optional)	Semtech/Stackforce Semtech/Stackforce with modifications IBM IBM with modifications Proprietary- Other, name it:
2.32 LoRaWAN Stack Version (optional)	V1.0.2
2.33 LoRa Radio Hardware (optional)	☑Proprietary: SX chip used: ☐LoRaWAN Modem/Module: Manufacturer: Part Number: Firmware revision:
2.34 Multicast support (optional)	☐Yes: Multicast DevAddr: Multicast AppSKey: Multicast NwkSKey: Payload: Port: ☑No.



3 Radio Frequency Information

3.1 Type of Antenna	□Wire
	□PCB
	☐External
	⊠Other: (which type) Microstrip (Patch) Antennas
3.2 Antenna gain [dBi or dBd]	1.4dBi or
	dBd
3.3 Did you measure and take into account the	☐Yes, dB loss
loss between the modem and the antenna?	⊠No, why: We have match the impedance between the
	moderm and the antenna.
3.4 For LW 1.0.2 rev A or older devices: which	TXPower 0 (20dBm)
TXPower setting should be used on the	☐ TXPower 1 (14dBm)
network for your device*:	TXPower 2 (11dBm)
	TXPower 3 (8dBm)
	TXPower 4 (5dBm)
	TXPower 5 (2dBm)
	other txpower (dBm)
3.5 Did you calibrate your device with the	⊠Yes, 1.4 dB loss
antenna gain and measured loss in between	□No, why:
the chipset and antenna? This so that your	
device emits with maximal power when using	
TXPower 1 for LW 1.0.2 rev A or older devices	
(= 14dBm) and TXPower 0 for LW 1.0.2 rev B or newer devices (= MaxEIRP or 16.15dBm	
EIRP)*.	
<u> </u>	



4 Battery and TX Power Information

Please indicate if you do not want Section 4 displayed on the LoRa Alliance Website Yes If yes please supply contact details for the operators to request the information for Section 4

4.1 Battery consumption of the	TX current: 62-64mA
device (including modem,	RX current: 6.7 mA
sensors and all other electronics	Idle time current: 0.0058mA
4.2 Estimated battery life in years based on the number	Battery life in years
of transmissions (including sensor readings) at SF7,	≥ SF7 SF10 SF12
SF10 & SF12 with your battery self-discharge and aging over time taken into account.	<u>S</u> 144 62.98 27.6 8.1
over time taken into account.	은 중 96 75.18 37.2 11.78
Accumentions	SF7 SF10 SF12
Assumptions: - Product shelf life before use:	<u></u>
	<u>.∞</u> . <u>∞</u> . <u>∞</u> .12 113.7 95.3 56.3
Maximum 1 year.	ទ្ធ ទ្ធ 4 119 112 88.1
 At an environment temperature of 20°C. 	্ট্র ট্র 1 122 120 111.7
01 20 C.	F
- LoRaWAN specification used for battery life	□LW1.0.1
calculation:	□LW1.0.2 revA
oaloulation.	⊠LW1.0.2 revB
	Other:
- TX power setting (txpower)	□LW1.0.1
used for battery life calculation:	LW1.0.2 revA
acca ioi acaici, iiic caicailaileiii	□ LW1.0.2 revB
	Other:
- Payload size used for battery life	16 bytes
calculation (should be average	10 27.00
payload size of production device):	
pay. Tall one of production devices.	
- Additional assumptions or	
comments on battery life (Typical usage	
Transfer on ballory me (Typical dodge	



- If LW 1.0.2 rev A or older device: TXPower 0 (20dBm)	4.3 Which TX power setting (TXPower) was used in the RF test?	
TXPower 1 (MaxEIRP-2dB) TXPower 2 (MaxEIRP-4dB) TXPower 3 (MaxEIRP-6dB) TXPower 4 (MaxEIRP-8dB) TXPower 5 (MaxEIRP-10dB) TXPower 6 (MaxEIRP-10dB) TXPower 7 (MaxEIRP-12dB) TXPower 7 (MaxEIRP-14dB) other TXPower 14.6 (MaxEIRP-1.4 dBdBm) 4.4 Is this the same TX power setting (TXPower) used by default in production devices (before network ADR)? 4.5 Maximum ERP measured: (ERP = EIRP - 2.15 dB; LoRaWAN allows 14 dBm ERP) 4.6 TRP measured: (TRP is based on EIRP) This gives an idea about the directivity of the antenna. 3.10 TIS measured on RX1: For RX1-SF12BW125 on 868.3MHz -146 dBm		☐ TXPower 1 (14dBm) ☐ TXPower 2 (11dBm) ☐ TXPower 3 (8dBm) ☐ TXPower 4 (5dBm) ☐ TXPower 5 (2dBm)
(TXPower) used by default in production devices (before network ADR)? 4.5 Maximum ERP measured: (ERP = EIRP - 2.15 dB; LoRaWAN allows 14 dBm ERP) 4.6 TRP measured: (TRP is based on EIRP) This gives an idea about the directivity of the antenna. 3.10 TIS measured on RX1: For RX1-SF12BW125 on 868.3MHz -146 dBm	- If LW 1.0.2 rev B or newer device:	☐ TXPower 1 (MaxEIRP-2dB) ☐ TXPower 2 (MaxEIRP-4dB) ☐ TXPower 3 (MaxEIRP-6dB) ☐ TXPower 4 (MaxEIRP-8dB) ☐ TXPower 5 (MaxEIRP-10dB) ☐ TXPower 6 (MaxEIRP-12dB) ☐ TXPower 7 (MaxEIRP-14dB) ☐ Other TXPower 14.6
2.15 dB; LoRaWAN allows 14 dBm ERP) 4.6 TRP measured: (TRP is based on EIRP) This gives an idea about the directivity of the antenna. 3.10 TIS measured on RX1: For RX1-SF12BW125 on 868.3MHz -146 dBm	(TXPower) used by default in production	l '
This gives an idea about the directivity of the antenna. 3.10 TIS measured on RX1: For RX1-SF12BW125 on 868.3MHz -146 dBm	· ·	14 dBm
	This gives an idea about the directivity of the	14 dBm
2 11 TIS managered on DV2	3.10 TIS measured on RX1:	For RX1-SF12BW125 on 868.3MHz -146 dBm
3.11 113 measured on RAZ	3.11 TIS measured on RX2	For RX2-SF12BW125 on 869.525 MHz: -146 dBm